Lab Sheet - 4

Simulation of continuous system

Objectives:

- To develop the mathematical modeling of the (continuous system) mass spring damper system.
- To determine the state of the system i.e. x, distance moved at different point of time.

Theory





Figure 1: A mass-spring damper system

The free body diagram of the above system is



According to Newton's law of motion, we have

Force= $Mass \times Acceleration$

The motion of the system is described by the following differential equation:

$$M \times \frac{d C(t)}{dt^{2}} = Kr(t) - \left(D\frac{dC(t)}{dt} + KC(t)\right)$$
$$M \times \frac{d^{2}C(t)}{dt^{2}} + D\frac{dC(t)}{dt} + KC(t) = Kr(t)$$

Therefore, the mathematical modeling of a mass spring damper system with mass M, force r(t), damper coefficient D, spring coefficient K and displacement C(t) is given by

$$M \times \frac{d^2C(t)}{dt^2} + D\frac{dC(t)}{dt} + KC(t) = Kr(t) \qquad ------ [I]$$

This equation can be re-written as

$$\frac{d^2C(t)}{dt^2} + \frac{D}{M}\frac{dC(t)}{dt} + \frac{K}{M}C(t) = \frac{1}{M}Kr(t) \qquad ------ [II]$$

Equation [I] is the mathematical model of the given Mathematical system. Comparing equation [II] with general second order partial equation.

$$\frac{d^{2}x(t)}{dt^{2}} + 2\xi W \frac{dx(t)}{dt} + W^{2}x(t) = W^{2}F$$

Where,

Damping ration $\xi = D/2.M.W$ Angular frequency of oscillation $W = \sqrt{K/M}$

The response of this system with unit step function depends on the value of ξ . The condition for the motion to occur without oscillation requires that ξ >=1. Show how x varies in response to a steady force applied at time t=0 for the various values of ξ .